

Portable Power Station



User Manual

1.Get To Know Your Gear




- 1 Main Power Button
- (2) AC Status Indicator
- ③ USB-C Input / Output
- 4 USB-A Output 2x5V/2.4A
- AC Power Output
- Remaining power level Indicator
- 7 DC Barrel Jack (DC 5521-5.5x2.1 mm)

2.Specification

Capacity:		154Wh (3.7V/41,600mAh)		
Battery Type:		Lithium-ion Cell		
USB-C Input / Output:		PD 60W Max (5V/3A,9V/3A,12V/3A,15V/3A,20V/3A)		
AC Output Power:		Rated Power: 160W / Peak Power: 200W		
Inverter Waveform:		Pure Sine Wave		
AC Output:		100-120V~ / 60Hz		
		220-240V~ / 50Hz	Option	
DC Output:	2x USB-A	5V/2.4A max		
	1x DC5521	DC 12V/10A Max	Option	Total Share 200W Max
		DC 24V/5A Max	Ориоп	
	1x USB-C	PD 60W		1
Dimension:		205x170x48mm / 8.0x6.7x1.8 inchs		

3.Charging Your Power Station

Please recharge the power station before you use or store long time per 3 months by any PD Adapter. Also you can use any 5V USB adapter via USB-C cable to charge your power station.



4.Turn on/off The Power Station

Press and hold 2 seconds the main power button to turn on the power station.


Press and hold 2 seconds the main power button to turn off the power station.

- * One short click the button to show remaining power level.

 Double click the main power button to switch on AC power.
- * Before you use DC(5521)Power,please switch on main power and keep it powers on.If only use USB-A or USB-C to charge devices you can plug and use directly no need turn on the main power.



5.How to Use AC Output Port



- 1.Plug in the main socket.
- 2.Switch ON

Double click the main power button to switch on AC power. The AC status indicator turn green to work. When power inverter is under faulty, the AC status indicator will change to red.

3.Swith Off

When finished using AC power, please double click the main power button to switch off the AC power to save the battery energy.